

1 Before driving

1-1. Key information	20	1-4. Opening and closing the windows and moon roof	64
Keys	20	Power windows.....	64
1-2. Opening, closing and locking the doors and trunk	22	Moon roof	66
Smart access system with push-button start	22	1-5. Refueling.....	69
Wireless remote control	34	Opening the fuel tank cap.....	69
Doors.....	37	1-6. Theft deterrent system.....	72
Trunk.....	41	Engine immobilizer system.....	72
1-3. Adjustable components (seats, mirrors, steering wheel).....	44	Alarm.....	74
Front seats.....	44	Theft prevention labels (U.S.A.).....	76
Driving position memory	46	1-7. Safety information.....	77
Seat position memory	49	Correct driving posture	77
Head restraints.....	51	SRS airbags	79
Seat belts	52	Front passenger occupant classification system.....	90
Steering wheel (manually adjustable type)	58	Child restraint systems	95
Steering wheel (power-adjustable type).....	59	Installing child restraints.....	98
Anti-glare inside rear view mirror	60		
Outside rear view mirrors.....	61		

2 When driving

2-1. Driving procedures.....	108
Driving the vehicle.....	108
Engine (ignition) switch	117
Automatic Transmission	122
Manual Transmission.....	126
Turn signal lever.....	128
Parking brake	129

2-2. Instrument cluster.....	130
Gauges and meters	130
Indicators and warning lights ...	136
Multi-information display.....	139
2-3. Operating the lights and windshield wipers.....	143
Headlight switch.....	143
Fog light switch	146
Windshield wipers and washer.....	147
Headlight cleaner switch	151
2-4. Using other driving systems....	152
Cruise control	152
Dynamic radar cruise control.....	155
Intuitive parking assist	164
Driving assist systems.....	170
PCS (Pre-Collision System).....	176
2-5. Driving information	179
Cargo and luggage.....	179
Vehicle load limits.....	182
Winter driving tips	183
Trailer towing.....	187
Dinghy towing (vehicles with an automatic transmission)	188
Dinghy towing (vehicles with a manual transmission).....	189

3 Interior features

3-1. Using the air conditioning system and defogger	192
Automatic air conditioning system	192
Rear window and outside rear view mirror defoggers	200
3-2. Using the audio system.....	201
Audio system type	201
Using the radio.....	204
Using the CD player.....	211
Playing back MP3 and WMA discs.....	217
Optimal use of the audio system	225
Using the AUX adapter.....	228
Using the steering wheel audio switches	229
3-3. Using the interior lights.....	231
Interior lights list.....	231
• Interior lights	234
• Personal lights	234

3-4. Using the storage features 236

List of storage features.....	236
• Glove box.....	236
• Console boxes	237
• Overhead console.....	238
• Cup holders.....	239
• Bottle holders/ door pockets.....	241

3-5. Other interior features..... 242

Sun visors.....	242
Vanity mirror.....	243
Clock.....	244
Satellite switches	245
Ashtrays	248
Cigarette lighter	249
Power outlet.....	250
Seat heaters.....	251
Seat heaters and ventilators	253
Armrest	255
Rear sunshade.....	256
Trunk storage extension.....	258
Coat hooks	259
Floor mat.....	260
Trunk features.....	261
Garage door opener.....	264
Compass.....	269

4 Maintenance and care**4-1. Maintenance and care..... 274**

Cleaning and protecting the vehicle exterior.....	274
Cleaning and protecting the vehicle interior	277

4-2. Maintenance..... 280

Maintenance requirements	280
General maintenance.....	282
Emission inspection and maintenance (I/M) programs	285

**4-3. Do-it-yourself
maintenance..... 286**

Do-it-yourself service precautions.....	286
Hood.....	289
Positioning a floor jack.....	290
Engine compartment.....	292
Tires	306
Tire inflation pressure.....	316
Wheels.....	320
Air conditioning filter	322
Electronic key battery	325
Checking and replacing fuses.....	327
Headlight aim.....	341
Light bulbs.....	342

5 When trouble arises

5-1. Essential information	350
If your vehicle needs to be towed	350
If you think something is wrong	356
Fuel pump shut off system	357
Event data recorder	358
5-2. Steps to take in an emergency	360
If a warning light turns on or a warning buzzer sounds... ..	360
If a warning message is displayed	369
If you have a flat tire.....	382
If the engine will not start	391
If the shift lever cannot be shifted from P	392
If you lose your keys	393
If the electronic key does not operate properly	394
If the vehicle battery is discharged	397
If your vehicle overheats	400
If the vehicle becomes stuck ...	402

6 Vehicle specifications

6-1. Specifications.....	406
Maintenance data (fuel, oil level, etc.).....	406
Fuel information.....	421
Tire information	424
6-2. Customization	436
Customizable features	436
6-3. Initialization	441
Items to initialize	441

7 For owners

Reporting safety defects for U.S. owners.....	444
Seat belt instructions for Canadian owners (in French).....	445

Index

Abbreviation list	448
Alphabetical index.....	450
What to do if... ..	462